

ADJUSTING THE RETENTION ON THE CROSSBREED RECKONING HOLSTER.



ADJUSTING THE TRIGGER GUARD RETENTION DEVICE:

Locate the trigger guard retention device located behind the trigger area of the kydex pocket. Using the provided 1/8th inch hex key; insert into the retention screw and turn clockwise in half turn increments until the desired level of retention is achieved. To loosen the retention, turn the key counterclockwise.



ADJUSTING THE RETENTION ON THE SHELL

Locate the screws on the right hand (when looking straight at the pocket) side of the holster. The screws will be under the clip and are accessible by pivoting the clip to the right, exposing the screws.

Using a standard phillips-head screwdriver turn each screw to adjust the retention turning clockwise for more retention and counterclockwise for less retention. The screws on both clips can also be adjusted in the same manner to achieve the desired retention.

CHANGING THE IWB CLIPS ON THE CROSSBREED RECKONING HOLSTER.



Locate the screws attaching the clips to the holster. Using a standard phillips-head screwdriver or drill remove the screws from the clips being careful not to lose the binding post on the back of the holster.

Remove the clips and set aside being sure to retain the rubber spacer located behind the standard clips.

Replace the standard clips with your desired clips being sure the rubber spacers remain in place.

If your new clips are equipped with multiple ride-height holes be sure you select the desired ride height at this time.

Re-insert and tighten the screws until the clips are secure

and the desired amount of retention has been achieved.

SWITCHING FROM INSIDE THE WAISTBAND TO OUTSIDE THE WAISTBAND CLIPS



Locate the screws attaching the clips to the holster. Using a standard phillips-head screwdriver or drill remove the screws from the clips being careful not to lose the binding post on the back of the holster.

Remove the clips and rubber spacers and set aside. Additionally set aside the long clip screws that come standard with the holster.

Locate the two (2) shorter screws included with the OWB Clip set.

Replace the previous screws with the new, shorter screws, setting the desired retention as you tighten.

Locate the OWB clips in the set. One clip will be marked "R" and the other "L" indicating the side of the holster the clip will be installed on.



NOTE: The "R" and "L" indicate the side of the holster when viewing the back (leather part) of the holster.

Using a standard phillips-head screwdriver or drill remove the screws holding in the trigger guard retention device being careful not to lose the "binding post" on the back of the holster or the retention device.

Remove the corresponding binding post from the back of the holster.

NOTE: Be sure the retention device remains in place and aligned with the holes on the kydex pocket and leather backer.

On the back of the holster, align the holes on the "R" OWB clip with the holes on the leather backer (you should be able

to see the "R" mark on the clip).

Re-insert the "binding post" and flip over to re-insert the phillips-head screws.



Tighten the screws; locking the clip in place.

On the opposite side of the holster select 2 adjacent screws for your "L" clip.

NOTE: The top 2 will give you a very slight forward cant, the middle 2 will give you no cant, and the bottom 2 will give you a slight rear cant.

Using a standard phillips-head screwdriver or drill remove the 2 selected screws being careful not to lose the "binding post" on the back of the holster or the rubber spacers.

Remove the corresponding "binding post" from the back of the holster.

NOTE: Be sure the rubber spacers remain in place and aligned with the holes on the kydex pocket and leather

backer.

On the back of the holster, align the holes on the "L" OWB clip with the holes on the leather backer (you should be able to see the "L" mark on the clip).

Re-insert the "binding post" and flip over to re-insert the phillips-head screws.

Tighten the screws; locking the clip in place.

For more information or if you have more question please visit www.crossbreedholsters.com or call our service line at 888.732.5011